



NOTES:

- 1) STRIKE LOCATION ON FRAMES MAY NEED ADJUSTED FOR THICKNESS WHEN DOOR SILENCERS ARE USED.
- 2) DOOR FRAME MANUFACTURERS STANDARD METHOD OF ATTACHMENT (WELDMENT).

TITLE		B80/B81 STRIKE PREP GUIDE (DEADBOLT STRIKE)		REV. DATE: 00-00-00	REV. --
DIMENSIONS—METRIC "DO NOT SCALE PRINT" TOLERANCES UNLESS OTHERWISE SPECIFIED: X.X = ±0.4 DEG. ±0.5 X.XX = ±0.15		APPVD: ---	DRAWN BY: JWB	ORIG. DATE: 04-03-13	
<b>Frascio International</b> 1011 3rd Avenue S.W. Carmel, Indiana 46032 PH. (317)663-0030 FAX (317)663-0029		SCALE: 1:2	Drawing NO: DP-176		