

NOTES:

- 1) ALIGNMENT OF THE 8mm SPINDLE IS CRITICAL. MAKE SURE IT IS SQUARE TO THE EDGE OF THE DOOR, THEN MARK FOR HOLES.
- 2) DRILL HOLES TO THE CORRECT DRILL DIAMETER DEPENDING ON FASTENER SIZE.
- 3) DIMENSIONS: MILLIMETERS ON TOP, [INCHES IN BRACKETS].
- 4) NOT FULL SCALE--DO NOT USE AS A PAPER TEMPLATE TO PREP DOOR.

Description:  
T600 DUMMY THRU BOLT DOOR PREP

TOLERANCES UNLESS OTHERWISE SPECIFIED:  
X.X (METRIC)= ±0.5  
X.XX(METRIC)= ±0.15  
0.00"(UNIFIED)= ±.015"  
0.000"(UNIFIED)= ±.005"

Drawing No:  
**DP-376**

Drawn By: **JWB**

Orig.Date: **12-06-21**

Rev. Date:

Rev.:

