

- NOTES:
- 1) MATERIAL: WOOD DOOR SUBSTRATE ONLY.
  - 2) DOOR PREP FOR BOTH RIGHT AND LEFT HAND. RIGHT HAND SHOWN. MIRROR DIMENSIONS FOR LEFT HAND PREP.
  - 3) FOR DOOR PREP INFORMATION ON THE VING ALLURE, SEE ORIGINAL ASSA ABLOY/VING DOOR PREP TEMPLATE AN-206.
  - 4) THIS TEMPLATE IS NOT 1:1 SCALE. DO NOT USE AS A 1:1 DOOR PREP TEMPLATE.

Description:  
FRASCIO SM TRIM FOR VING ALLURE  
RIGHT HAND PREP SHOWN

TOLERANCES UNLESS OTHERWISE SPECIFIED:  
X.X (METRIC) = ±0.5  
X.XX (METRIC) = ±0.15  
0.00" (UNIFIED) = ±.015"  
0.000" (UNIFIED) = ±.005"

Drawing No:  
**DP-434**

Drawn By: **JWB**

Orig. Date: **11-09-23**

Rev. Date: **07-10-25**

Rev.: **A**



DOOR INSIDE

DOOR OUTSIDE

