

NOTES:
 1) SOME DOOR PREP ALTERATIONS MAY BE NEEDED AT TIME OF INSTALLATION.
 2) POSITION CENTER OF STRIKE AT CENTER OF DEADLOCK CASE AND BOLT.
 3) AN ALTERNATE WAY TO FIND MOUNTING HOLE LOCATIONS IS TO PLACE STRIKE INTO THE FACEPLATE CAVITY, MARK CENTER OF MOUNTING HOLES, REMOVE AND DRILL.

Description:
SL2 STRIKE PREP

TOLERANCES UNLESS OTHERWISE SPECIFIED:
 X.X (METRIC)= ±0.5
 X.XX(METRIC)= ±0.15
 0.00"(UNIFIED)= ±.015"
 0.000"(UNIFIED)= ±.005"

Drawing No:
DP-470

Drawn By: **JWB**

Orig.Date: **11-15-24**

Rev. Date: Rev.:

