

- NOTES:
- 1) LEFT HAND SHOWN.
 - 2) DIMENSIONS IN PARENTHESIS ARE INCHES.
 - 3) HOLES: DO NOT DRILL THROUGH DOOR--ONE SIDE ONLY.
 - 4) DOOR PREP FOR 60mm BACKSET, (2-3/8"), RELOCATE TRIM HOLE PATTERN TO CORRECT BACKSET LOCATION.

Description:
T700 SERIES, 1-1/8", SQUARE CORNER
UL-HDY LATCH, COMM-PASSAGE, BLIND PREP



TOLERANCES UNLESS OTHERWISE SPECIFIED:
 X.X (METRIC)= ±0.5
 X.XX(METRIC)= ±0.15
 0.00"(UNIFIED)= ±.015"
 0.000"(UNIFIED)= ±.005"

Drawing No: DP-544	
Drawn By: JWB	Orig.Date 6-10-26
Rev. Date:	Rev.:

