

NOTES:

- 1) MAKE CERTAIN THAT ALL DIMENSIONS ARE DRILLED/MACHINED PROPERLY.
- 2) SOME ADDITIONAL DOOR PREP ADJUSTMENTS MAY BE NECESSARY ON SITE.
- 3) ALL CORNERS ARE TO BE SQUARE FOR PROPER FIT OF THE RECESSED PULL.

Description:

RPE54305 X DPA4005 BTB SET
DOOR PREP



TOLERANCES UNLESS OTHERWISE SPECIFIED:
X.X (METRIC)= ±0.5
X.XX(METRIC)= ±0.15
0.00"(UNIFIED)= ±.015"
0.000"(UNIFIED)= ±.005"

Drawing No:

DP-548

Drawn By:

JDK

Orig.Date

07-06-26

Rev. Date:

Rev.:

OUTSIDE

INSIDE

SECTION A-A

