

- NOTES:
- 1) REFERENCE THE FUNCTION/TRIM CHART FOR CORRECT HOLE DRILLING.
 - 2) STRIKEPLATE AREA TO BE RECESSED 4.0mm [.156"] DEEP.
 - 3) POSITION STRIKE PLATE INTO CAVITY AND MARK MOUNTING HOLES WITH PUNCH. REMOVE STRIKE. IF STEEL FRAME: PRE-DRILL $\varnothing.171$ (11/64") AND TAP FOR #12-24 or IF WOOD, PRE-DRILL $\varnothing.156$ (5/32").
 - 4) BE CERTAIN CORRECT SIDE OF DOOR SURFACE IS DRILLED ACCORDING TO HANDING OF THE DOOR.

Description:
**MD SERIES MORTISE DEAD LOCK
 DOOR PREP (RIGHT HAND SHOWN)**



TOLERANCES UNLESS OTHERWISE SPECIFIED:
 X.X (METRIC)= ± 0.5
 X.XX(METRIC)= ± 0.15
 0.00"(UNIFIED)= ± 0.015 "
 0.000"(UNIFIED)= ± 0.005 "

Drawing No:
DP-216

Drawn By: **JWB**

Orig.Date: **12-22-14**

Rev. Date: **09-17-24**

Rev.: **C**



CAREFUL ATTENTION TO FUNCTION AND HANDING WILL DETERMINE HOLE REQUIREMENTS AND PLACEMENT.

TABLE				
	LEFT HAND		RIGHT HAND	
FUNCTION	INSIDE HOLE-A	OUTSIDE HOLE-B	INSIDE HOLE-A	OUTSIDE HOLE-B
MD1	A	B	A	B
MD2	B	B	B	B
MD3	B	B	B	B
MD4	A	A	A	A
MD5	NONE	B	NONE	B

SEE NOTE 5

DOOR PREP

