





- NOTES:
- 1) FUNCTION: PASSAGE (PA) OR PRIVACY (PY).
 - 2) DIMENSIONS "X" AND "Y" ARE VARIABLE DEPENDING ON DOOR THICKNESS.
 - 3) STRIKE LOCATION ON FRAMES MUST BE ADJUSTED FOR THICKNESS OF DOOR SILENCERS WHEN USED.
 - 4) FOR RIGHT HAND OPERATION, MIRROR DIMENSIONS TO OTHER SIDE OF JAMB.
 - 5) THIS DOOR PREP DRAWING IS NOT FULL SCALE--DO NOT USE AS FULL SIZE TEMPLATE.
 - 6) THIS TEMPLATE PROVIDES INFORMATION FOR BOTH PASSAGE AND PRIVACY LATCHES.
 - 7) IT IS BEST TO DRILL HALF-WAY THRU DOOR FROM EACH SIDE TO ELIMINATE DRILL WONDER/AXIAL MIS-ALIGNMENT. THIS SHOULD PROVIDE A MORE PRECISE HOLE PREP.
 - 8) THIS DOOR PREP IS FOR BOTH 60mm AND 70mm BACKSETS. USE ONLY ONE FOR THE APPROPRIATE BACKSET.

NOT FULL SCALE

Description: T600/RML TUBULAR DOOR PREP (RMLSTK1)	Drawing No: DP-413	
	Drawn By: JWB	Orig.Date 05-25-23
 <small>1011 3rd Avenue S.W. Carmel, IN. 46032</small>	Rev. Date:	Rev.:

LATCH PREPARATION

RMLSTK1 STRIKE PREPARATION
(LEFT HAND SHOWN--SEE NOTE 4 FOR HANDING)



NOT FULL SCALE